

A diagram illustrating deep-layer vertical wind shear. On the left, a vertical line represents a surface or boundary. Arrows of varying lengths and directions originate from this line at different heights, pointing towards the right. The arrows at higher altitudes are longer and more horizontal, while those at lower altitudes are shorter and more angled upwards. In the background, a large, billowing white cumulus cloud rises against a blue sky with scattered white clouds. The overall scene suggests a cross-section of a storm system where wind direction and speed change with altitude.

Deep-layer Vertical Wind Shear

To answer in-class questions go to: pollev.com/severeclass641

Deep-layer Vertical Wind Shear



What is it?

Where does it come from?

What is its influence on deep convection?

How do we measure it?

How to forecast it?


Vertical Wind Shear

What is it?


Defined as:

“The condition produced by a change in wind velocity (speed and/or direction) with height.”
- AMS Glossary


Speed Shear



Directional Shear



Combination of both
(most common)



Vertical Wind Shear Where does it come from?

Primary contribution:

“Large-scale horizontal temperature gradients via the thermal-wind relation”
(M.R. 2010)

$$(1) u_g = -\frac{g}{f} \frac{\partial Z}{\partial y} \quad \text{geostrophic wind}$$

$$(2) \frac{\partial Z}{\partial p} = -\frac{RT}{gp} \quad \text{hypsoetric eqn}$$


plug (2) into (1)

$$\begin{aligned} \frac{\partial u_g}{\partial p} &= \frac{g}{f} \frac{\partial}{\partial y} \left(\frac{RT}{gp} \right) \\ &= \frac{R}{fp} \frac{\partial T}{\partial y} \end{aligned}$$

finite difference expression:

$$\Delta u_g = \frac{R}{f} \frac{\Delta p}{p} \frac{\Delta \bar{T}}{\Delta y} \quad \text{this is the thermal wind: an increase in wind with height due to a temperature gradient}$$

The thermal wind blows ccw around cold pools in the same way as the geostrophic wind blows ccw around lows. The thermal wind is proportional to the T gradient, while the geostrophic wind is proportional to the pressure (or height) gradient.




For additional reading: M.R. 2010 and Doswell 1991



Vertical Wind Shear Where does it come from?

Secondary contributions:

Large accelerations of the horizontal wind due to large ageostrophic winds
(think near jet streaks, areas of frontogenesis, and/or rapidly intensifying cyclones).



Erodes horizontal
temperature gradient
(weaker thermal wind)




Enhances horizontal
temperature gradient
(stronger thermal wind!)

For additional reading: M.R. 2010 and Doswell 1991


Vertical Wind Shear Where does it come from?

Tertiary contributions: Boundary-layer friction, which may be present in the absence of large-scale baroclinicity (think Ekman Spiral).


- In the free atmosphere (free of friction), the wind is geostrophic (i.e., parallel to isobars due to the balance between pressure gradient and Coriolis force)



- Close to the surface, friction will cause a deviation of the wind direction from geostrophic solution (flow from high to low pressure)



- Consequences:
 - wind speed increases with altitude
 - wind direction changes with altitude in form of a spiral, the so-called **Ekman Spiral**




For additional reading: M.R. 2010 and Doswell 1991

True or False: It is inappropriate to have both a horizontally homogeneous environment AND strong wind shear in an idealized simulation of deep convection.



Vertical Wind Shear Influence on convection?



The role of deep-layer vertical wind shear is to displace negatively buoyant air and hydrometeors away from the updraft region.


This favors storm longevity and (perhaps more importantly) is the origin of mesocyclone rotation.

(Much more on that idea later in the class!)

Vertical Wind Shear



Simulation of a T-storm in a low-shear environment.
(Note the single updraft pulse followed by a quick collapse.)

Vertical Velocity Cross Section




Reflectivity Cross Section

20180701_2200_38.898_-89.976 Cross Section (t=60.0 s)
X position: 0




Vertical Wind Shear

How do we measure it?



Bulk Wind Difference:

The magnitude of the vector difference between the winds at two different levels.



Vertical Wind Shear

How do we measure it?




Fig. 1 from Brooks et al. 2003

Surface to 6 km BWD is a very common metric to gauge the magnitude of deep-layer wind shear.

Many studies have shown that around 10 m/s (~20 knots) is a reasonable discriminator between severe and non-severe environments. (although not perfect!)

Other common BWD metrics used in convective forecasting include:

- 0-1 km BWD
- 0-3 km BWD
- 0-8 km BWD

Vertical Wind Shear


How do we measure it?

0-6 km Bulk Wind Difference Pros:

- Quick estimate of whether or not the environment will support downdraft displacement from the updraft region (i.e. will the environment support storm venting).
- Very easy to calculate and interpret.

0-6 km Bulk Wind Difference Cons:

- Does not contain information about the “shape” of the wind profile (i.e. there is no information about the hodograph).
- **May not accurately represent the layer of the atmosphere contributing to deep convection.**




Vertical Wind Shear


How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Is the surface parcel contributing to the updraft?



Is the surface parcel is contributing to the updraft?



Yes

No




Vertical Wind Shear

How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

How about this parcel (green)?
Probably!




Vertical Wind Shear

How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

How about this parcel (green)?
Probably!

Parcels below this layer are NOT contributing to the updraft, therefore we don't want to consider the parcel's trajectory/wind velocity in shear calculations.



Vertical Wind Shear

How do we measure it?


0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

≥ 100 J/kg CAPE

≥ -250 J/kg CIN



Vertical Wind Shear


How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

- $\geq 100 \text{ J/kg CAPE}$
- $\geq -250 \text{ J/kg CIN}$



Vertical Wind Shear

How do we measure it?


0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

$\geq 100 \text{ J/kg CAPE}$

$\geq -250 \text{ J/kg CIN}$



Vertical Wind Shear


How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

- $\geq 100 \text{ J/kg CAPE}$
- $\geq -250 \text{ J/kg CIN}$



Vertical Wind Shear


How do we measure it?

0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

- ≥ 100 J/kg CAPE
- ≥ -250 J/kg CIN



Vertical Wind Shear

How do we measure it?


0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:

$\geq 100 \text{ J/kg CAPE}$

$\geq -250 \text{ J/kg CIN}$



Vertical Wind Shear

How do we measure it?


0-6 km BWD may not accurately represent the layer of the atmosphere contributing to deep convection.

Let's identify *all* of the parcels that are contributing to the storm's updraft.

We'll use the criteria:



$\geq 100 \text{ J/kg CAPE}$

$\geq -250 \text{ J/kg CIN}$



Vertical Wind Shear

How do we measure it?




Which will have a higher tornado potential? Why?

Vertical Wind Shear

How do we measure it?

“Deep-layer” shear should represent the storm’s depth

Simulations show sufficient shear
near
from 0 to 5/6 km AGL sustains
supercells...




Vertical Wind Shear

How do we measure it?

“Deep-layer” shear should represent the storm’s depth

Simulations show sufficient
near
from 0 to 5/6 km AGL sustains
supercells...

But we can use the Eff. inflow layer to consider the depth from the CAFE bearing layer to the FI




Vertical Wind Shear

How do we measure it?

“Deep-layer” shear should represent the storm’s depth


Simulations show sufficient
near
from 0 to 5/6 km AGL sustains
supercells...

But how do we define the bottom of this layer? Top of the eff. layer? Bottom of the eff. layer?



Calculating Effective Bulk Shear

2) Find EL of most-unstable parcel



100% Base-EL depth

75% Base-EL depth


50% Base-EL depth

25% Base-EL depth


3) Find BWD between inflow base and some % of the base-EL layer

1) Start at the effective inflow base


Effective Bulk Shear Percentiles (surface-based storms)



Effective Bulk Shear Percentiles (surface-based storms)



Effective Bulk Shear Percentiles (surface-based storms)




Effective Bulk Wind Difference

- BWD between the bottom of the Eff. Inflow layer and 50% of the [Eff. inflow layer - EL] layer depth.
- Similar to 0-6 km Bulk Wind Difference in “typical” (surface-based) scenarios
- More flexible than 0-6 km BWD
 - Captures shallow and deep buoyancy environments
 - Captures elevated thunderstorm environments

Vertical Wind Shear

How to forecast it?

Use Q.G. methods to anticipate how the wind profile will change.



Using the Q.G. Height tendency equation, how will the 500 mb field change over the next 8-12 hours?

What will this do to the winds at 500 mb over Dodge City, KS (red dot)?

Assuming steady state conditions near the ground, what will this do to the 0-6 km BWD?

What will happen to the 0-6 km BWD over the next 8-12 hours?

Increase

Decrease

Stay the same


Impossible to tell!



Vertical Wind Shear

How to forecast it?

Use Q.G. methods to anticipate how the wind profile will change.



Using the Q.G. Height tendency equation, how will the 500 mb field change over the next 8-12 hours?


What will this do to the winds at 500 mb over Dodge City, KS (red dot)?

Assuming steady state conditions near the ground, what will this do to the 0-6 km BWD?

Vertical Wind Shear

How to forecast it?

Use Q.G. methods to anticipate how the wind profile will change.



Using the Q.G. Omega equation, will the 850 mb low over the CO/NE/WY region deepen or weaken?

What will this do to the winds at 850 mb over Norman, OK (red dot)?

Assuming steady state conditions near the ground, what will this do to the surface to 850 mb BWD?

*also consider thermal wind response of tightening 850 mb thermal gradient.

What will happen to the sfc-850 mb BWD at Norman, OK over the next 8-12 hours?

Increase

Decrease

Stay the same


Impossible to tell!



Vertical Wind Shear

How to forecast it?

Use Q.G. methods to anticipate how the wind profile will change.



Using the Q.G. Omega equation, will the 850 mb low over the CO/NE/WY region deepen or weaken?

What will this do to the winds at 850 mb over Norman, OK (red dot)?

Assuming steady state conditions near the ground, what will this do to the surface to 850 mb BWD?

*also consider thermal wind response of tightening 850 mb thermal gradient.